



CENTURY INDUSTRIES CORPORATION

A Century Group Company

5331 STATE ROUTE 7 NEW WATERFORD, OH 44445 800-955-8443

PRODUCT SPECIFICATION SHEET



PRODUCT NAME

CENTURY "THREE T" TAPING, TOPPING & TEXTURING LIGHTWEIGHT COMPOUND

ITEM CODE

335-03 (3.5 Gallon)

UPC CODE

017581 33503 2

V.O.S./V.O.C.

Maximum V.O.S./V.O.C. is 1.7 lbs. per gallon.

FORMULATION

Dolomitic Limestone/Crystalline Silica

DESCRIPTION

Up to 35% lighter than ordinary compounds, this smooth, ready-mixed, extra white formulation excels for taping of drywall joints, as a topping finish and as a texture finish for interior surfaces. This multi-purpose formula is "super-light" with less shrinkage than standard compounds, providing excellent results in any application. Many different texture finishes can be achieved with a broad knife, stiff brush, sponge, towel, crumpled paper, roller, etc.

DIRECTIONS

TAPING: Beginning with a 4" broad knife, apply compound evenly and fully into wallboard joint, filling the channel formed by the wallboard edges. Embed tape in center of channel and run tape the length of the joint. Hold the tape firmly at the top of joint and press tape firmly into compound with the broad knife. Remove excess compound and reapply to form a skim coating over the tape. Allow to dry for a minimum of 24 hours.

TOPPING: Using an 8" broad knife, apply a second thin, even coat of compound making sure to feather the edges. Always allow 24 hours to dry between applications. If a third coat is required, use a 10" or 12" broad knife and repeat the process. When the last application is thoroughly dry the compound should be lightly sanded with a fine (200 grit) paper, being careful not to expose tape or roughen paper of exposed wallboard.

TEXTURING: The surface to be textured must be free of grease, dirt or loose particles. All glossy surfaces should be sanded before texturing. Stir contents thoroughly prior to use. For best results, compound should be roller applied with a heavy nap roller in small (4' x 4') sections. Many different texture finishes can be achieved with a stiff brush, sponge, trowel, crumpled paper, roller, etc. Coverage will be approximately 100-250 sq. ft. per pail depending on texture desired.

ADDITIONAL TIPS: Always stir product thoroughly before and during application. Wet sanding with a damp sponge is recommended whenever practical. After application, protect surface with an overcoat of quality interior paint for maximum durability.

THINNING: Joint compound may be thinned by adding clean water sparingly in half pint increments. Remix completely after each addition. Over-thinning may result in excessive shrinkage, edge cracking, reduced bond, and generally poor working characteristics.

CAUTION: Sanding dust may cause eye, nose, throat or upper respiratory irritation. Prolonged and continued exposure to a high concentration of airborne dust may result in delayed lung injury. If dry sanding, wear a NIOSH/MSHA approved respirator for protection from dust. Do not take internally. If ingested, induce vomiting. Call physician at once. The use of safety glasses is recommended. Eye contact: Remove contact lenses. Rinse eyes with water for 10-15 minutes, including under eye-lids. If irritation continues, contact physician at once.

IMPORTANT: Do not mix with any other wet or dry material. Do not expose contents to extreme heat or sunlight. Close container tightly after use. Always store and apply in above freezing temperatures. If material becomes frozen, let thaw naturally. Remix before use to a smooth, even consistency.

COVERAGE

Approximately 100-250 sq. ft. per pail.

CLEAN UP

Wash hands and tools with soap and water.

PACKAGING

3.5 gallon plastic pails.